

Smart Bidet Seat Toilet Suite



Tel: 03 9998 0999 Email: sales@hellokitchen.com.au

www.hellokitchen.com.au

INSTALLATION MANUAL

Model: SL620D



INTELLIGENT TOILET

P-TRAP Installation Manual

Cautions for safety. Please observe the following rules.

**The following symbols are used to indicate important safety instructions for the use of the product.

⚠ Danger	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
<u></u> Warning	Indicates dangerous situations where the user could suffer death or serious injury if this product is used incorrectly.
Do not dismantle	Indicates not to dismantle this product.
Observe	Indicates to observe the following precaution before using this

* Tip.When you have multiple smart toilets,set them to different channels for remote control.

- Setting channel steps:
- 1.Please plug in the toilet.
- 2.Press the STOP button on the toilet panel, hold down the button.
 3.Meanwhile press MALE CLEANING button to change the channel.
- 4. There are 8 channels for you to choose, you can hear different beep on
- different channels.Choose one of them.
- 5.Take out the remote control, hold down the two buttons"+""-"until hearing the beep,release the buttons immediately. Channel setting is complete.
- * Note:Press the"CHOOSE"button for 3 seconds to open or close the motion sensor.


2 Install the Battery box


Put the battery in the battery box, then connect the Battery box to the toilets.



P-trap installation

Adjust the position of the toilet drain outlet, and then connect the toilet to the wall.
















Battery box

4 Install shutoff valve

- 1.Close the main water supply
- 2. Wind Teflon tape around water shutoff valve
- 3. Connect the shutoff Valve, tighten up with wrench.
- 4. Connect the constant perssure valve.

Note: After installing the shutoff Valve, please turn on the water supply and Valve to flush the dirt for 30s and check whether there is a leakage.



Connect the hose

Fix the hose to the Constant pressure valve



Apply glass glue.


- 1.Flush the toilets and find whether there is a leakage with a paper.
- 2.Water may get into the part between the lower end of the toilet and the floor and leave stain.Apply glass glue(Not Concrete)to prevent water penetration.





Connect Power

- 1.Insert the power plug into the outlet
- 2. Turn on the shutoff valve.
- 3. Press the flush button on the remote control to do a test.












Floor drain S-Trap (Standard services/Concealed services)



PS:SL:150mm 240mm 300mm 400mm S:160mm 240mm 300mm 400mm R:165mm 230mm 300mm 400mm



Wall drain P-Trap (Standard services/Concealed services)





Diameter of Water Outlet 1/2'G Inlet Water Hose Length 60cm Length of Power Cord 100cm

Water Pressure Minimum 150kPa.Maximun 750kPa,nominal fixed flush volume was 5L

Electrical Standard 10amp power point required

Installation To be carried out by a licensed plumber installation as per local region, concil plumbing specifications and plumbing codes additional back flow device may be a requirement

The position of the power outlet and water outlet can also be flexible according to the real situation.

S-TRAP Installation Manual

Cautions for safety. Please observe the following rules.

product.

different channels Choose one of them

**The following symbols are used to indicate important safety instructions for the use of the product.

<u> </u>	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 Warning	Indicates dangerous situations where the user could suffer death or serious injury if this product is used incorrectly.
ODo not	Indicates not to dismantle this product

* Tip.When you have multiple smart toilets,set them to different channels for

3.Meanwhile press MALE CLEANING button to change the channel 4. There are 8 channels for you to choose you can hear different been on

the beep,release the buttons immediately. Channel setting is complete.



5.Take out the remote control, hold down the two buttons"+""-"until hearing ★ Note:Press the"CHOOSE"button for 3 seconds to open or close the motion sensor

Indicates to observe the following precaution before using this



Accessories







Install the Battery box

Put the battery in the battery box, then connect the Battery box to the toilets.




Install the Flange on the floor

1.Fix the flange on the bottom

Connect the toilet with flange to the drain pipe on the floor
 Slightly press the toilets after the toilet connected to make the connection more better.




Note: The expansion pipe type toilets do not need flange, just connect the Drain pipe directly.



4 Install shutoff valve

- 1.Close the main water supply
- 2.Wind Teflon tape around water shutoff valve 3.Connect the shutoff Valve, tighten up with wrench.
- 4. Connect the constant perssure valve.

Note: After installing the shutoff Valve, please turn on the water supply and Valve to flush the dirt for 30s and check whether there is a leakage.



Connect the hose


Fix the hose to the Constant pressure valve







- 1. Flush the toilets and find whether there is a leakage with a paper.
- 2. Water may get into the part between the lower end of the toilet and the floor and leave stain. Apply glass glue (Not Concrete) to prevent water penetration.



Connect Power

- 1.Insert the power plug into the outlet
- 2. Turn on the shutoff valve.
- 3 Press the flush button on the remote control to do a test.



